

# Ithaca Products

<u>PART NO.</u>	<u>DESCRIPTION</u>
126619	Feedroll Shaft
1884074	Space Rack
06-0710	Carriage Cable Tape
06-0875	Cutter Shear Plate Spring
06-1109	Cutter Shear Plate
09-1230	Spindle Paper Supply (Large)
09-1494	Spindle Paper Supply (Small)
09-1570	Assembly Cutter Transport Module
09-1710	Rotary Cutter
70-02220	Main Harness
75-02153	Assembly Interconnect PCB
75-02245	Main Chassis Assembly
85-03510	Assembly Harness 30 Position-Ribbon
85-03526	Assembly RS232 Interface PCB

<u>PART NO.</u>	<u>DESCRIPTION</u>
98-02230	Lamp
98-02231	Lamp Socket
98-02240	Slides (1 Pair)
98-02241	Velcro Hook
98-1579	Springs Comp Arm Helper
E030063-01	Assembly Controller PCB (w/o ROM)
M034647-01	Assembly Print Mechanism
M034656-01	Assembly Cover & Platen
M034658-01	Assembly Paper Low Sensor
M750	M750 Printer
M75-P	M75-P Printer, Parallel Port w/ Autocut
M75-S	M75-S Printer, Serial Port w/ Autocut
M76-P	M76-P Printer, Parallel Port w/ Autocut
M76-S	M76-S Printer, Serial Port w/ Autocut
M850	M850 Printer

## M850 & M860 Parts List

<u>PART NO.</u>	<u>DESCRIPTION</u>
M034653-01	Assembly-3/3 Straight Harness
85-03510	Assembly-30 Cond Ribbon Cable
M034650-01	Assembly-Harness 16 Pos
M034655-01	Assembly-Interface Harness
85-03500	Assembly-M850/860 Comm/Power Adapter
E030063-01	Assembly-M850/860 Standard Controller PCB
E030062-01	Assembly-Netplex Interface PCB
Rm034656-01	Assembly-Replacement Cover And Platen
Rm034660-01	Assembly-Replacement Latch Shaft
Rm034654-01	Assembly-Replacement Motor/Switch Harness
Rm034648-01	Assembly-Replacement Netplex Outer Slide
Rm034658-01	Assembly-Replacement Paper Low Sensor
R85-03677	Assembly-Replacement PCB Cover Plate
Rm034651-01	Assembly-Replacement Platen And Gear
R85-00533	Assembly-Replacement Rap PCB Harness
R85-00525	Assembly-Replacement Rap Print Mech
R85-03499	Assembly-Replacement Rap Sensor Tip
R85-00524	Assembly-Replacement Serial Outer Slide
Rm034647-01	Assembly-Replacement Standard Printer Mech
Rm034659-01	Assembly-Replacement Ticket Taken Sensor
Rm034657-01	Assembly-Replacement Top Of Form Sensor
85-03526	Assembly-Rs232 Interface
M068263-01	Bearing-Platen
M068278-02	Bracket-Front Low Paper
M068259-02	Chassis-Inner Slide
M068258-01	Chassis-Outer Slide
M068266-02	Chassis-Printhead

<u>PART NO.</u>	<u>DESCRIPTION</u>
M068317-01	Clip-Spring
98-03559	Clip-Wire Harness Whc-125-01
M068272-01	Gear-54/16 Tooth
M068312-02	Guide-Lower Rear Paper
M068271-01	Guide-Printhead Spring
M068275-01	Guide-Slide Rail
98-0621	Nut-M3 Hex With Lockwasher
M068262-01	Plunger-Slide
M067832-03	Printhead-Thermal
520-9800002	Retainer-E Ring .125 Dia
520-9800003	Retainer-E Ring .156 Dia
M067908-01	Screw-#2-28 X 7/16 Tap PHD PHPS R80-00022
M067883-03	Screw-#6-18 X 1/4 Tap PHD PHPS
98-2034	Screw-M3 X 16 PHD PHPS
98-02215	Screw-M3 X 6mm Sems PHD PHPS
M066711-04FLRX	Screw-M4 X 6 PHD PHPS
85-03532	Shield-Plunger Guide
09-1283	Spacer-Pivot Pin
M068316-01	Spring-Leaf Latch
M068279-01	Spring-Printhead Compression
M068333-02	Spring-Rap
85-03552	Spring-Slide Plunger
M068274-01	Stop-Slide Block
M068323-01	Strap-Slide Ground
85-03672	Tray-200 Ticket With Label
85-03673	Tray-400 Ticket With Label
85-03674	Tray-600 Ticket With Label
98-0941	Tywrap-3 3/8